

Accessories

Manage and control accessories connected to the monitor.

Remote



Use this section to pair up to three [bluetooth remotes](#) to your monitor for bump-free menu access.

 The remote is a great option for steadicam, gimbal, crane/jib or even sensitive tripod work because it allows you to access the entire monitor without physically coming in contact with it.

[Remote Slots]

SLOT	STATUS
1	ACTIVE
1	FOUND
1	EMPTY



Pairing the remote:

To connect the remote, go to the menus under remote and be sure its enabled. Hold the blue joystick down for about 5 seconds, you should see the Remote link under the status column. Select it on the monitor and it will “bind”. Once this is tied (Active), it will work as a normal joystick would. It will blink blue light slowly when paired. It will blink fast blue when not paired.

💡 If a bluetooth remote is found within range (make sure to remove the battery cover on the remote) it will display as 'Found' - select this to pair your remote which will change the readout to 'Active'. After that you should be all set!

TROUBLESHOOTING TIPS

*Remotes will remain paired to a specific monitor and will need to be Unpaired if you want to use it with a different monitor.

*BT-1 remotes update with firmware when they first pair, it is recommended if you have not used the remote recently, to allow 3-4 minutes for the remote to update upon first pairing.

*If the remote is blinking red and blue quickly, you will need to replace the batteries. It takes 2x CR1620 watch style batteries.

*More BT-1 Remote Tips [here](#).